SIMPLE HI Bold

ZEITRAUM

Aufbauanleitung 07/2022

WERKZEUG:

Innensechskantschlüssel SW4 und SW5 (beiliegend), Kreuz-Schlitz Schraubendreher

14x XS Bolzen	3x Gewindestangen (M8x70)
14x Verbindergehäuse	3x Gewindestangen (M8x215)
14x Madenschrauben	3x Mittelfüße, verstellbar
24x Confirmatschrauben	3x Abstandsklötze (100x60x40)
3x Hülsenmuttern (M8)	3x Abstandsklötze (40x60x40)



Funktionsvideo:
https://www.youtube.com/watch?v=ioIUTDqtvgE

*Führen Sie den Aufbau des Bettes **auf einer weichen Unterlage (z.B. einer Decke)** aus, um Beschädigungen zu vermeiden.*



1 Kopf- und Fußteil
2 Längsseiten
3 Quertraversen
4 Bett- und Mittelfüße
5 Mittelsteg und seitliche Auflageleisten
6 Abstandsklötze



1. Bolzen in die Längsseiten **(2)** eindrehen und Verbindergehäuse in mittlere Quertraverse **(3)**, Kopf- und Fußteil **(1)** einstecken. Bolzen und Gehäuse richtig ausrichten!



2. Kopf- und Fußteil aufstecken und mit Madenschrauben fixieren.



3. Die Bettfüße **(4)** auf die äußeren Quertraversen aufstecken und diese an der Bettseite montieren. Die mittlere Quertraverse mit XS Verbindern sichern.

4. Zweite Längsseite aufstecken und mit Verbindern fixieren.



5. Seitliche Halteleisten und Mittelsteg **(5)** mit den Confirmatschrauben befestigen.



6. Die Hülsenmuttern auf die Gewindestangen (kurze Gewindestangen nur für unterste Einlegetiefe) schrauben. Die richtigen Abstandsklötze **(6)** nach der gewünschten Einlegetiefe auswählen. Die Mittelfüße unter den Quertraversen positionieren und die Gewindestangen von oben festdrehen. Den Mittelfuß festhalten und in der Höhe einstellen.



ohne Abstandsklotz: Einlegetiefe 24,5 cm

liegender großer Abstandsklotz: Einlegetiefe 18,5 cm

stehender großer Abstandsklotz: Einlegetiefe 14,5 cm

beide Abstandsklötze: Einlegetiefe 10,5 cm

Hinweis: Bei Betten mit Holzkopfteil auf genügend großen Abstand zur Wand achten, um eine ausreichende Luftzirkluation sicherzustellen

ZEITRAUM GmbH • Äußere Münchner Straße 2 • D-82515 Wolfratshausen • Tel +49 (0) 8171 – 418130 • Fax +49 (0) 8171 – 418141 • info@zeitraum-moebel.de • www.zeitraum-moebel.de

SIMPLE HI Bold

ZEITRAUM

Assembly instructions 07/2022

TOOLS:

allen key SW4 und SW5 (enclosed), crosstip screwdriver

14x XS steel dowels	3x threaded rods (M8x70)
14x connector housings	3x threaded rods (M8x215)
14x grub screws	3x center support feet, adjustable
24x Confirmat screws	3x distance blocks (100x60x40)
3x sleeve nuts (M8)	3x distance blocks (40x60x40)



Watch this video for further information on the metal fitting:
https://www.youtube.com/watch?v=ioIUTDqtvgE

*Please assemble the bed **on a soft surface (e.g. a carpet or blanket)** to avoid damages.*



1 head and footboard
2 side rails
3 crossbars
4 bed and center support feet
5 center rail and support bars
6 distance blocks



1. Screw XS dowels into the side rails **(2)** and insert the connector housings into head and footboard **(1)**. Align dowels and housings correctly!



2. Attach the head and footboard to the side rail and fix them with grub screws.



3. Attach the two bed feet **(4)** to the crossbars **(3)**.Mount the crossbars to the bed side. Fix the center crossbar with XS connectors.

4. Connect the second side rail and fix it with grub screws.



5. Fix the support bars and center rail using Confirmat screws.



6. Screw the sleeve nuts onto the threaded rods (short threaded rods only for lowest position). Choose the right distance blocks **(6)** according to the insertion depth. Position the center support feet under the crossbars and screw in the threaded rods (or the countersunk bolts for the lowest insertion depth) while holding the center support feet. Adjust the height of the center support feet.



without distance block: insertion depth 24,5 cm

horizontal big distance block: insertion depth 18,5 cm

vertical big distance block: insertion depth 14,5 cm

both distance blocks: insertion depth 10,5 cm

Note: For beds with a wooden headboard, ensure sufficient distance from the wall to ensure adequate air circulation

ZEITRAUM GmbH • Äußere Münchner Straße 2 • D-82515 Wolfratshausen • Tel + 49 (0) 8171 – 418130 • Fax + 49 (0) 8171 – 418141 • info@zeitraum-moebel.de • www.zeitraum-moebel.de